



## ARNE JACOBSEN

Design: Arne Jacobsen

Designed in 1957 by celebrated Danish architect Arne Jacobsen, the ARNE JACOBSEN cutlery pattern is revered for its futuristic, yet ironically timeless design. Created originally for the SAS Royal Hotel in Copenhagen, the cutlery was highly controversial when launched in mid 1950's for its minimalism and architectural refinement ensuring a stark expression. The narrow form and the slender contours of ARNE JACOBSEN have made it a cult design classic. It has been featured in Stanley Kubrik's 2001: A Space Odyssey and other futuristic films making it one of Georg Jensen's most popular patterns. ARNE JACOBSEN is produced in matte stainless steel.

011 Spiseske Dinner Spoon Tafellöffel 20 cm / 8 inches	012 Spisegaffel Dinner Fork Tafelgabel 20 cm / 8 inches	014 Spisekniv, langt skaft Dinner Knife, long handle Tafelmesser, langer Griff 20 cm / 8 inches	017 Spisekniv, langt skaft, grill Dinner Knife, long handle, serrated Tafelmesser, langer Griff, Wellenschliff 20 cm / 8 inches	021 Dessertske Dessert Spoon Dessertlöffel 18,5 cm / 7 3/8 inches	022 Forrets-/Frokost-/ Dessertgaffel Starters/Lunch/ Dessert Fork Vorspeise-/ Dessertgabel 18,5 cm / 7 3/8 inches	025 Forrets-/Frokost-/ Dessertkniv Starters/Lunch/ Dessert Knife Vorspeise-/ Dessertmesser 19 cm / 7 1/2 inches	031 Teske, stor/ Barneske Tea Spoon, large/ Child's Spoon Teelöffel, groß/ Kinderlöffel 15,6 cm / 6 1/8 inches	033 Teske, lille Tea Spoon, small Teelöffel, klein 13,5 cm / 5 3/8 inches	034 Kaffeske Coffee Spoon Kaffelöffel 11,4 cm / 4 1/2 inches	046 Smørkniv Butter Spreader Buttermesser 16,5 cm / 6 1/2 inches
053 Suppe-/ Morgenmadsske, højre hånd Soup/ Breakfast Spoon, right hand Suppen-/ Frühstücksöffel, rechte Hand 16,5 cm / 6 1/2 inches	056 Suppe-/ Morgenmadsske, venstre hånd Soup/ Breakfast Spoon, left hand hand Suppen-/ Frühstücksöffel, linke Hand 16,5 cm / 6 1/2 inches	082 Barnegaffel/ Kagegaffel Child's Fork/ Pastry Fork Kindergabel/ Kuchengabel 16,5 cm / 6 1/2 inches	111 Serveringsske Serving Spoon Vorlegelöffel 28 cm / 11 inches	112 Serveringsgaffel Serving Fork Vorlegegabel 28,5 cm / 11 1/4 inches	134 Espressoske 2 stk., gaveæske Espresso Spoon 2 pcs., gift box Espressolöffel 2 Stck., Geschenkbbox 11,4 cm / 4 1/2 inches	153 Sauceske Sauce Ladle Saucenlöffel 16,5 cm / 6 1/2 inches	178 Cafelatteske/ Isteske, 2 stk., gaveæske Cafe Latte Spoon/ Ice Tea Spoon, 2 pcs., gift box Caffè Latte-Löffel/ Limonadenlöffel, 2 Stck., Geschenkbbox 18,5 cm / 7 3/8 inches	191 Kagespade Pie Server Tortenheber 25,5 cm / 9 7/8 inches	502 Serveringssæt Serving Set Vorlegebesteck 32 cm / 12 5/8 inches	503 Salatsæt Salad Set Salatbesteck 28,5 cm / 11 1/4 inches

## VEDLIGEHOELSE AF STÅLBESTIK

### BESTIK I BEDSTE STÅLKVALITET

Georg Jensen bestik i rustfrit stål er fremstillet i den bedst tilgængelige stålkvalitet rustfrit (stainless) 18/8 (18% krom og 8% nikkel).

### SÅDAN VASKES RUSTFRIT STÅL

Vask og tør altid bestikket umiddelbart efter brug. Bestikket bør ikke ligge uvasket og heller ikke lægges i blød over længere tid, da det kan forårsage pletter. Ved maskinopvask skylles bestikket af, inden det placeres i maskinen. Undlad at vaske bestikket op sammen med produkter af jern da de kan afgive rust. Tør bestikket af umiddelbart efter opvaskemaskinen er færdig.

### PAS GODT PÅ BESTIKKET

Ved at tage enkelte forholdsregler holdes bestikket pænt.

Forsøg at undgå stærkt klor og jernholdigt vand - det kan efterlade små rustpletter på bestikket.

Begræns så vidt muligt bestikkets kontakt med syre fra fødevarer - fødevarer såsom sennep og æg kan angribe stålet og give pletter.

Eventuelle pletter fjernes forsigtigt med Georg Jensen stålpuddsemiddel.

## STAINLESS STEEL CUTLERY CARE

### TOP QUALITY STEEL CUTLERY

Georg Jensen stainless steel cutlery is made of the best quality steel available: stainless 18/8 (18% chromium and 8% nickel).

### HOW TO WASH STAINLESS STEEL

Always wash and dry the cutlery shortly after use. Avoid leaving the cutlery unwashed or leaving it to soak for a long period as this may result in spotting. When using a dishwasher, rinse the cutlery before placing it in the machine. Do not wash the cutlery with products made from iron as they may give off rust. Wipe the cutlery dry soon after the dishwasher has finished.

### HANDLE WITH CARE

Keep the cutlery in good condition by taking a few precautions.

Try to avoid highly chlorinated or ferruginous water as this may leave small rust spots on the cutlery.

Try to limit the cutlery's contact with acids from food products. Food such as mustard and eggs can corrode the steel and cause spotting.

If spots occur, carefully remove the spots with Georg Jensen's steel polish.

## PFLEGEHINWEIS FÜR EDELSTAHLBESTECK

### BESTECK IN BESTER STAHLQUALITÄT

Georg Jensen Besteck aus rostfreiem Stahl wird aus der besten Stahlqualität hergestellt, die es gibt: Edelstahl rostfrei 18/8 (18 % Chrom und 8 % Nickel).

### SO SPÜLEN SIE ROSTFREIEN STAHL

Das Besteck immer unmittelbar nach dem Gebrauch abwaschen und abtrocknen. Besteck sollte nicht benutzt liegen gelassen und auch nicht längere Zeit eingeweicht werden, da dies zu Flecken führen kann. Bei einer Reinigung in der Spülmaschine das Besteck abspülen, bevor es in den Besteckkorb gegeben wird. Das Besteck nicht zusammen mit Produkten aus Eisen spülen, da diese Rost abgeben können, und das Besteck direkt nach Beendigung des Spülvorgangs abtrocknen.

### SO BLEIBT IHR BESTECK LANGE SCHÖN

Durch die Beachtung einfacher Verhaltensmaßregeln bleibt Ihr Besteck lange schön.

Stark chlor- und eisenhaltiges Wasser nach Möglichkeit vermeiden, da es kleine Rostflecken auf dem Besteck verursachen kann.

Den Kontakt des Bestecks mit säurehaltigen Lebensmitteln so weit wie möglich beschränken - Lebensmittel wie Senf und Eier können den Stahl angreifen und zu Flecken führen.

Flecken bei Bedarf vorsichtig mit Georg Jensen Stahlputzmittel entfernen.